



- International and European Tones (programmable)
- PA and non-PA models available
- Audible sense feature included as standard
- 100w or 60w selectable
- Low current `standby' feature
- Positive and negative triggers
- 12 or 24 volt models available
- Reduced size due to SMD technology (120x95.5x51.5mm)
- Tone selector accessible externally
- Run cool circuit and aluminium enclosure with improved heat dissipation
- Improved connectors
- EMC/R10 compliant
- 2 year warranty
- Manufactured in the United Kingdom





### Description

The Redtronic siren range have had many improvements including reduced size, easier selectable options, improved aesthetics and heat sinking capability. The latest 2018 release is available from July 2018 onwards. Previous versions will be discontinued.

#### **Part Numbers**

ORDER CODE	DESCRIPTION	WATT	VOLT
EM500.100.12.IN	EM500 SIREN UK/INT TONE (IN DIP1246) {NO SPEAKER}	100W	12V
EM500.100.12.FR	EM500 SIREN FRANCE TONE (EU DIP12) {NO SPEAKER}	100W	12V
EM500.100.12.AU	EM500 SIREN AUSTRIA TONE (EU DIP2) {NO SPEAKER}	100W	12V
EM500.100.12.CY	EM500 SIREN CYPRUS TONE (EU DIP4){NO SPEAKER}	100W	12V
EM500.100.12.DE	EM500 SIREN GERMAN TONES (EU DIPO) {NO SPEAKER}	100W	12V
EM500.100.12.FI	EM500 SIREN FINLAND TONE (IN DIP5) {NO SPEAKER}	100W	12V
EM500.100.12.IT	EM500 SIREN ITALY TONE (IN DIP34) NO SPEAKER	100W	12V
EM500.100.12.NL	EM500 SIREN NETHERLAND TONE (IN DIP1) NO SPEAKER	100W	12V
EM500.100.12.NO	EM500 SIREN NORWAY TONE (IN DIP25) NO SPEAKER	100W	12V
EM500PA.100.12.IN	EM500 SIREN PA & MIC UK/INT TONE (IN DIP1246) {NO SPEAKER}	100W	12V
EM500PA.100.12.FR	EM500 SIREN PA & MIC FRANCE TONE (EU DIP12) {NO SPEAKER}	100W	12V
EM500PA.100.12.AU	EM500 SIREN PA & MIC AUSTRIA TONE (EU DIP2) {NO SPEAKER}	100W	12V
EM500PA.100.12.CY	EM500 SIREN PA & MIC CYPRUS TONE (EU DIP4){NO SPEAKER}	100W	12V
EM500PA.100.12.DE	EM500 SIREN PA & MIC GERMAN TONES (EU DIPO) {NO SPEAKER}	100W	12V
EM500PA.100.12.FI	EM500 SIREN PA & MIC FINLAND TONE (IN DIP5) {NO SPEAKER}	100W	12V
EM500PA.100.12.IT	EM500 SIREN PA & MIC ITALY TONE (IN DIP34) {NO SPEAKER}	100W	12V
EM500PA.100.12.NL	EM500 SIREN PA & MIC NETHERLAND TONE (IN DIP1) {NO SPEAKER}	100W	12V
EM500PA.100.12.NO	EM500 SIREN PA & MIC NORWAY TONE (IN DIP25) {NO SPEAKER}	100W	12V

SPEAKERS SHOULD BE ORDERED SEPERATELY.

### **Tones (brief description)**

• EM500: Standard UK/International tones (Wail, Yelp, Hi/Lo, Phaser & Bullhorn)

• EM500EUR: European tones

### Mounting / fixing

EM500: 2 x Screw pointsEM500EUR: 2 x Screw points

### **Wattage Output**

• 60 or 100watt (dipswitch selectable)

#### Warranty

Siren (independent unit): 2 yearsSiren (fitted inside lightbar): 2 years





Tac	hnical	п	nfor	mai	ion

Model	EM500	EM500EUR	EM500/PA	EM500EUR/PA
Tone / Frequency (Hz)	Standard: 600 -	German: 360-630	Standard: 600-1750	German: 360-630
rone / rrequency (riz/	1500	Austrian: 392-523		Austrian: 392-523
		Dutch: 375-500		Dutch: 375-500
		French: 435-740		French: 435-740H
		Italian: TBC		Italian: TBC
		Cypriot: TBC		Cypriot: TBC
		Norway: TBC		Norway: TBC
Voltage	12v (10-16V)	12v (10-16V)	12v (10-16V)	12v (10-16V)
Available in 24v?	YES (EM500/24)	YES (EM500EUR/24)	NO	NO
Typical RMS (100w)	105	105	105	105
PA facility	NO	NO	YES	YES
Current draw (100watt)	9 amps	9 amps	9 amps	9 amps
Current draw low power (60watt)	6 amps	6 amps	6 amps	6 amps
Current draw in standby	20ma	20ma	20ma	20ma





### Decibel outputs (with speakers)

Siren	Tone	1 metre	2 metre	3 metre	3.5 metre	7 metre
		EM500 STAND	ARD SIREN (UK & IN	NTERNATIONAL)		
S100SL						
S60C						
S100LP	INT Wail		107.7			
	INT Yelp		110.5			
	INT Hi-Lo		101.5			
	INT Phaser		106.6			
EM60P/RC	INT Wail	115.9		112		97.9
EM60P/PC						
S20IS	INT Wail	121.7		114		101.3
		EM5	00GER – GERMAN 1	TONES		
S100SL						
S60C						
S100LP	GER Country	115.9	110.4	103.1	101.5	100.9
	GER City	112.9	106.7	106.2	102.9	99.1
	GER Komp	110.9	107.3	107.2	105.2	98.4
EM60P/RC						
EM60P/PC						
S20IS						
		EM	500FRE - FRENCH TO	ONES		
S100SL						
S60C						
S100LP						
EM60P/RC						
EM60P/PC						
S20IS	FR Police		113.6			
	Day					
	FR Police		93.7			
	Night					
	FR Fire Day		112.8			
	FR Fire Night		95.5			
	FR Amb Day		113.2			
	FR Amb		89.8			
	Night					





				10.00											
Code	Tone(s)	Cable	Cable	Cable	tted Cable	Cable	Notes	1	2	3	4	5	6	7	8
Coue	EM500 STANDARD SI					Cable	Notes	1		3	4	3	0	,	٥
IN1	W-Y-OFF-W	+ve	-ve	WH	PH	C/O		OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
IN2	W-Y-W	+ve	-ve	WH	PH	C/O		ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF
IN3	W-Y-H/L-OFF-W	+ve	-ve	WH	PH	C/O		OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF
	,				STAN	DARD SETTIN	NG								
IN4	W-Y-H/L-W	+ve	-ve	WH	PH	C/O		ON	ON	OFF	ON	OFF	ON	OFF	OFF
INIT	W V DU OFF W			VAZLI		DARD SETTIN	NG I	055	OFF	ON	055	055	055	055	055
IN5	W-Y-PH-OFF-W W-Y-PH-W	+ve	-ve	WH WH	PH PH	C/O C/O		OFF	OFF	ON	OFF OFF	OFF OFF	OFF	OFF OFF	OFF
IN6 IN7	H/L-Y-W-OFF-H/L	+ve +ve	-ve	WH	PH	C/O		OFF	ON	ON ON	OFF	OFF	OFF	OFF	OFF
IN8	H/L-Y-W-H/L	+ve	-ve -ve	WH	PH	C/O		ON	ON	ON	OFF	OFF	OFF	OFF	OFF
1110	Double tap off	176	-ve	VVII		C/ C	Enable /	011	O, t	0.11		011	011	011	011
	'						disable				ON				
	Bullhorn	+ve	-ve				Enable / disable						ON		
	Bullhorn (only)	+ve	-ve					ON	OFF	OFF	OFF	ON	OFF	OFF	OFF
	PA (only)							OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON
	EM500 STANDARD SI	IREN (FIN	INISH TO	NES)											
FI1	H/L-Y (6 sec burst)	+ve	-ve					OFF	OFF	OFF	OFF	ON	OFF	OFF	OFF
	EM500GER – GERMA	N TONES													
GE1	Country (+ve)	+ve					+ve	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
	Country (-ve)		-ve				-ve	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
	City			-ve			-ve	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
	Kompressor				-ve		-ve	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
	EM500AUS - AUSTRIA		S (FIRE)												
AU1	Fire Plain (+ve)	+ve					+ve	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF
	Fire Plain (-ve)		-ve				-ve	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF
	Fire Vibrato Fire Vibrato			-ve			-ve w/	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF
	riie vibrato				-ve		brown/blue	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF
	EM500AUS - AUSTRIA	AN TONE	S (RETTU	NG)											
AU2	Rettung Plain (+ve)	+ve					+ve	OFF	ON	ON	OFF	OFF	OFF	OFF	OFF
	Rettung Plain (-ve)		-ve				–ve	OFF	ON	ON	OFF	OFF	OFF	OFF	OFF
	Rettung Vibrato			-ve			-ve	OFF	ON	ON	OFF	OFF	OFF	OFF	OFF
	Rettung Vibrato				-ve		W/ brown/blue	OFF	ON	ON	OFF	OFF	OFF	OFF	OFF
	EM500AUS - AUSTRIA	AN TONE	S (SPECIA	AL)											
AU3	Special Plain (+ve)	+ve					+ve	OFF	ON	ON	ON	OFF	OFF	OFF	OFF
	Special Plain (-ve)		-ve				–ve	OFF	ON	ON	ON	OFF	OFF	OFF	OFF
	Special Vibrato			-ve			-ve	OFF	ON	ON	ON	OFF	OFF	OFF	OFF
	Special Vibrato				-ve		W/ brown/blue	OFF	ON	ON	ON	OFF	OFF	OFF	OFF
	EM500AUS - AUSTRIA	AN TONE	S (POLICE	Ε)			brown, blue								
AU4	Police Plain (+ve)	+ve					+ve	OFF	ON	OFF	ON	OFF	OFF	OFF	OFF
	Police Plain (-ve)		-ve				-ve	OFF	ON	OFF	ON	OFF	OFF	OFF	OFF
	Police Vibrato			-ve			-ve	OFF	ON	OFF	ON	OFF	OFF	OFF	OFF
	Police Vibrato				-ve		W/	OFF	ON	OFF	ON	OFF	OFF	OFF	OFF
	EM500DUT - DUTCH	TONES					brown/blue								
DU1	Standard (+ve)	+ve					+ve	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF
	Standard (-ve)		-ve				-ve	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF
	Vibrato			-ve			-ve	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF
	Vibrato				-ve		W/	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF
DU2	Add. Vibrato (+ve)	LVO					brown/blue		OFF		OFF	OFF	OFF	OFF	OFF
D02	Add. Vibrato (+ve)	+ve	V0		+ve		+ve	ON ON	OFF	ON ON	OFF	OFF	OFF	OFF	OFF
	Add. vibrato (-ve)		-ve	-ve	-ve		-ve	ON	OFF	ON	OFF	OFF	OFF	OFF	OFF
	EM500FRE - FRENCH	TONES		VC			VC	011	OII	OIT	OII	OII	OII	OII	0.1
FR1	Police (+ve)	+ve					+ve	ON	ON	OFF	OFF	OFF	OFF	OFF	OFF
	Police (-ve)		-ve				-ve	ON	ON	OFF	OFF	OFF	OFF	OFF	OFF
FR2	Fire (+ve)	+ve			Samu		+ve	ON	ON	ON	OFF	OFF	OFF	OFF	OFF
	Fire (-ve)		-ve		Samu		-ve	ON	ON	ON	OFF	OFF	OFF	OFF	OFF
FR3	Samu (+ve)	+ve			Amb		+ve	ON	ON	OFF	ON	OFF	OFF	OFF	OFF
	Samu (-ve)		-ve		Amb		-ve	ON	ON	OFF	ON	OFF	OFF	OFF	OFF
FR4	Gendamerie (+ve)	+ve					+ve	ON	ON	ON	ON	OFF	OFF	OFF	OFF
	Gendamerie (-ve)		-ve				-ve	ON	ON	ON	ON	OFF	OFF	OFF	OFF
FR5	Ambulance (+ve)	+ve					+ve	ON	OFF	ON	ON	OFF	OFF	OFF	OFF
	Ambulance (-ve)		-ve				-ve	ON	OFF	ON	ON	OFF	OFF	OFF	OFF
															- 41. M



	EM500ITA - ITALIAN T	ONES													
IT1	Police (+ve)	+ve					+ve	OFF	OFF	ON	ON	OFF	OFF	OFF	OFF
	Police (-ve)		-ve				-ve	OFF	OFF	ON	ON	OFF	OFF	OFF	OFF
	Ambulance (-ve)				-ve		-ve	OFF	OFF	ON	ON	OFF	OFF	OFF	OFF
	EM500ITA - CYPRIOT TONES														
CY1	Police (+ve)	+ve					+ve	OFF	OFF	OFF	ON	OFF	OFF	OFF	OFF
	EM500NOR - NORWAY	/ TONES													
	Wail (+ve)	+ve					+ve	OFF	ON	OFF	OFF	ON	OFF	OFF	OFF
	Wail (-ve)		-ve				-ve	OFF	ON	OFF	OFF	ON	OFF	OFF	OFF
	Whoop			-ve			-ve	OFF	ON	OFF	OFF	ON	OFF	OFF	OFF
	Yelp (-ve)				-ve		-ve	OFF	ON	OFF	OFF	ON	OFF	OFF	OFF
	Yelp (+ve)					+ve	+ve	OFF	ON	OFF	OFF	ON	OFF	OFF	OFF

### Fault Finding / Diagnostic LED

If there seems to be a fault with the EM500, your auto electrician should monitor the number of flashes the diagnostic LED provides. The following table should help determine the issue:

LED State / Number of Flashes	Fault
Permanently illuminated	Normal operation
1 Flash	Speaker not connected / weak
2 Flashes	Overload detected after normal operation
3 Flashes	Overload detected as soon as siren started
4 Flashes	Undervoltage detected
5 Flashes	Speaker not connected / weak &undervoltage is detected
6 Flashes	Overload detected after normal operation & undervoltage is detected
7 Flashes	Speaker not connected / weak & overload detected after normal
	operation & undervoltage detected
8 Flashes	Over temperature trip
16 Flashes	Current detection circuit fault
No illumination	Check power and cable connections





### Dimensions



