




Electronics for Mobile & Marine

DWM-ANT

Omniantenne for DWM



Settle in Pole

Parts:

1. Staple
2. Hexangular screw
3. Spring washer
4. Fix mount
5. Antenna body

Settle in even surface

Parts:

1. Peg
2. Setscrew
3. Fix mount
4. Antenna body

Bruges i stedet for monitorens egen antenne.

Monteres vertikalt bag førehuset for maksimale modtagerforhold.