


ADP - 37

*ADAPTER FOR UNIVERSAL USE OF SHUTTER CAMERA


NOTE!

The shutter from the camera will open automatically
when the yellow trigger wire from the ADP-37 is activated by DC10 ~ 32V

← **MONITER**



● CONNECTION



● CONNECTOR PIN DESCRIPTION

