BatteryLink[®] Chargers NEW

Charge two batteries at or away from the dock with a 10A multistage battery charger and integrated 65A Automatic Charging Relay (ACR)

- AC charging at the dock: Use AC shore power to charge two isolated battery banks with the 3 Stage 10 Amp battery charger
- DC charging away from the dock: Share the DC power from the alternator with both the Start and the Auxiliary battery through the integrated 65A ACR
- Battery Temperature Compensation prolongs battery life
- Start isolation protects sensitive electronics from voltage sags and spikes
- Includes LED remote indicator for charge status at the helm
- Snap-on insulating cover
- One-piece stainless flange nuts ensure safe and secure connections

Specifications

12V DC Nominal Output Voltage **Total Output Current Output Connections** Universal AC Input Voltage Input Frequency Range Typical Float Voltage ACR Continuous Rating ACR Intermittent Rating (5 min.) ACR Combine Voltage (2 min.) ACR Combine Voltage (30 sec.) ACR Open Voltage (10 sec.) ACR Open Voltage (30 sec.) Operating Current (No AC Power, ACR Open) Operating Current (No AC Power, ACR Closed) 60mA Positive Cable Size (to meet current ratings) Negative Cable Size (to meet current ratings) Maximum Cable Size Terminal Stud Size Maximum Terminal Stud Torque Quick Connect Terminal Size Warranty Battery Types Maximum Battery CCA Recommended Battery Bank Sizes* (for optimal charging efficiency)

10A 2 positive, 1 negative 90V-265V AC 50/60 Hz 13.5V DC 65A 115A 13.0V 13.5V 12.35V 12.75V 10mA 6 AWG (16mm²) 10 AWG (6mm²) 1/0 AWG (50mm²) 1/4"-20 (accepts M6 ring terminal) 60 in-lb (6.8 Nm) 1/4" x 0.032" 5 Year Flooded, AGM, TPPL 850 CCA 60Ah Minimum, Example: 1 × Group 24 120Ah Maximum,

Example: 2 × Group 24 * Battery bank sizes are tested to California Energy Commission compliance (CEC). Larger and smaller size banks could charge well, but consume slightly more power over the charging cycle.

Regulatory

Designed and constructed for compliance to UL-1236 Marine, CSA 22.2 No. 107.2, and ABYC A-31 standards. Ignition Protection per ISO 8846, and SAE J1171. Meets FCC Part 15, Class B requirements. IP67 - protected against immersion up to 1 meter for 30 minutes

Specifications subject to change. See bluesea.com for current information.

PN	Description	Plug Style
7605	BatteryLink [®] Charger	North American: NEMA 5-15P
7604	BatteryLink [®] Charger	European: CEE 7/7

Related Products





Mini Add-A-Battery Plus Kits p. 37



тесн tip

AC & DC Battery Charging Explained AC Charging (At the Dock)

The BatteryLink[®] Charger works like a typical AC charger. When you plug in the AC cord, power is supplied allowing up to 10 amps of current to charge the connected batteries. Unlike a typical two bank charger, the BatteryLink[®] Charger will charge both batteries simultaneously through the integrated ACR. When AC power is present, the ACR will combine both batteries and the AC charger will charge them as one bank. For this reason the BatteryLink[®] Charger can only be used in 12V applications.

DC Charging (Away from the Dock)

The BatteryLink® Charger incorporates DC charging through an integrated 65A Automatic Charging Relay (ACR). An ACR uses a relay combined with a voltage sensing circuit. When a DC charge is being applied to either battery, and causes the voltage to rise above 13.0V, the relay closes and combines the two batteries to share the charge. When the charge is taken away or a load on the battery causes the voltage to drop below 12.75V, the relay will open, isolating the two batteries. This means that even when the BatteryLink® Charger is disconnected from AC power you can charge both your battery banks with an onboard DC charging source, like an engine alternator.

