



Safety First! Before beginning the installation and/or operation of your LEDs, the installation technician and operator must read this manual in full, *before* installation. This document provides all the necessary information to allow your product to be properly and safely installed to prevent severe injury or damage.

Proper installation of this product requires the installer to have a good understanding of automotive electronics, systems and procedures. Do not stare directly into these lights. Momentary blindness and/or eye damage could result. Do not install this product or route any wires in the deployment area of your air bag. Equipment mounted or located in the air bag deployment area will damage or reduce the effectiveness of the air bag or become a projectile that could cause serious personal injury or death. Refer to your vehicle owner manual for the air bag deployment area. The User/Installer assumes full responsibility to determine proper mounting location, based on providing ultimate safety to all passengers inside the vehicle. If this product uses a remote device to activate or control this product, make sure that this control is in an area that allows both the vehicle and the control to be operated safely in any driving condition. Do not attempt to activate or control this device in a hazardous driving situation.

If mounting this product requires drilling holes, the installer must be sure that no vehicle components or other vital parts could be damaged by the drilling process. Check both sides of the mounting surface before drilling begins. Also, de-burr any holes and remove any metal shards or remnants. Install grommets into all wire passage holes. For this product to operate at optimum efficiency, a good electrical connection to chassis ground must be made. The recommended procedure requires the product ground wire to be connected directly to the NEGATIVE (-) battery post or vehicle chassis. Do not attach the NEGATIVE (-) wire to any other existing ground wire. It is recommended that these instructions be stored in a safe place and referred to when performing Maintenance and/or reinstallation of this product. FAILURE TO FOLLOW INSTRUCTIONS COULD RESULT IN DAMAGE TO THE PRODUCT OR VEHICLE AND/OR SEVERE INJURY TO YOU AND YOUR PASSENGERS!



Control up to four lights (two 10 Amp and two 20 Amp) with this remote-controlled switchbox. The handheld remote has a range of 50 feet and comes with a LED indicator and self-adhesive tape. Please note the switchbox is not waterproof and must be mounted on a clean and dry location.

Switchbox Power Cables (in the rear of box)

- Connect Red wire to +12 Volts
- Connect Black wire to -12 Volts (ground)

Switchbox Outputs

- Screw LED red wire under "20A" or "10A" positive (+) terminal
- Screw the LED black wire under "20A" or "10A" negative (-) terminal
- Be noted - the outputs are switched on/off at the mass-side, not on the positive-side.

Remote Handheld Controller

- Powered by 23A 12V Alkaline battery (included)
- Buttons 1 and 4 connect to 20 Amp output, Buttons 2 and 3 connect to 10 Amp output
- Point the remote control to the main unit and using a small screwdriver, press the black switch. Press any one of the four buttons on the remote to pair. The green light will turn off indicating successful pairing.