

MXN81CN


AUTO HEATED, INFRA RED COLOR CAMERA




Contents








Bracket x 1





Camera x 1

Sun-shield x 1

Camera Screw Kit x 1 Screw cap cover x 4

Instruction manual x 1


Features

- Best picture quality (in combination with Digital LCD monitor)
- High resolution CMOS camera (1.23Mega pixels)
- 1/3.2" Color CMOS high resolution image sensor
- IP69K Waterproof Rating
- Diagonal 130° Viewing
- Normal/Mirror Image switching
- Ultra low light performance
- Automatic Electronic Iris
- Built-in Microphone
- Built-in IR LED's
- Built-in Automatic Heater (below +10°C)
- Temp. -40°C ~ 80°C
- Vibration resistant
- Waterproof screw type connector (IP67), 4-pin mini-DIN.
- E-mark.


Technical Specifications

| Image Sensor | 1/3.2" Color SONY CMOS(Exmor) |
|-----------------------|--|
| Scanning System | NTSC, 1.23Mega pixels(1280x960) |
| Resolution | 750 TV Lines |
| S/N ratio | Minimum 45dB (at AGC off) |
| Minimum Illumination | 0 lux (IR LED's on) |
| Power supply | DC 9 ~ 48V |
| Power Consumption | DC 12V, 220mA (Heater on) DC 12V, 132mA (Heater off) |
| Operating Temperature | -40°C to +80°C |
| Field of View angle | 130° (Diagonal), 102.2° (Horizontal), 72.8° (Vertical) |
| Dimensions | 95.9(W) x 43(H) x 62.8(D) mm 109.2(W) x 85.5(H) x 80(D) mm (incl.bracket & sunvisor |
| Weight | 326g (total weight incl. bracket & sunvisor: 464g) |

Front View



Rear View




Installation

Camera Assembly

Cable grommet

Drill a suitable hole (approx. Ø 19mm) and insert the cable grommet.

Just before final fixation, please apply a proper sealant (for prevention) between the hole and the grommet and also between the cable and the grommet.



- 1. Fix the supplied mounting bracket to the vehicle.
- 2. Fix the bracket with camera and sun-shield according to drawing.
- 3. Adjust the viewing angle of the camera and fasten the screws firmly.

Securing cable connection

Match the arrow marks and press the connectors together.




- 2. Screw the camera connector up clockwise.
- 3. Tighten cable connection firmly in order to prevent water ingress.

Note!

The warranty will not be valid if the problem is related to moist / corrosion in the connector.

Wiring to Monitor



Caution !!

- 1. Before making the connection, disconnect the ground terminal from the battery to avoid short circuits.
- 2. The plugs should be fully inserted into the connectors or jacks. A loose connection may cause malfunctioning of the unit.
- 3. A damaged cable may affect the operation of the camera and may even cause a malfunction of the camera or monitor: Avoid a damaged cable!
- 4. Protect the cable by using a guide tube, pipe or run the cable inside the vehicle as much as possible. Caution! Run the cable in natural shapes in order to prevent cable breaks.
- 5. Preferably use an acid free grease in between the waterproof screw type connectors and tighten them firmly eachother.